

Experiment No - 1

Aim :- Debugging a VI, sub VI's

Software used :- Lab View

Theory :- Program subroutines are termed as VIs. Each VI has 3 components :-



- 1) Block Diagram
- 2) Front Panel
- 3) Connector Panel

Front Panel :- It is made by using controls and indicators. Block diagram includes objects such as terminals, sub VI's functions, constants, structures & wires which transfer data.

While Loop :- It is a control flow statement used to execute a block diagram of the sub-diagram code repeatedly until a given boolean condition is not true.

DBL numeric constant is used to pass a double precision floating point numeric value to the block diagram.

Conclusion :- Sub VI's were created for temperature & level measurement & debugged the VI.



Handwritten signature and date: 4/2/2010

Experiment No-2

Aim:- LabView - Traffic light + programming structure, arrays, clusters

Software used : LabView



Theory:- Traffic light :- It is an optical signalling device indicates different signal related to traffic, rail, ~~to~~ naval etc. It aims at traffic safety.

Programming Structure :- programs can run depending on the value of variables. Structure can be found in LabView structure pallet. You need to draw the cases are for both true & false values.

Arrays :- These functions are used to create & manipulate arrays. You can perform common array operations such as extracting individual data element from an array, inserting, deleting or replacing data elements.

Clusters :- They group data elements of mixed types.
eg:- Error cluster in LabView.

Result :- Traffic lights using structures, clusters & arrays were implemented successfully.



Slav
4/2/2020

ray

0	0.774625	0.33317	0.25555
0	0.259811	0.70166	0.22884
0	0.15000	0.99999	0.16588

red

herf

p fi

Experiment NO-3

Aim :- LabView - Waveform Measurement

Software used :- LabView 2018

Theory :- Express VIs

The express VI is a VI whose setting you can configure interactively through a dialog box. Express VIs appear on block diagram as expandable nodes with icons successfully by blue field. A parameter can be configured and expanded from both locations.

Front Panel : it is the user interface of the VI.

Block Diagram :- It includes terminals, functions, constants, structures and wire which can transfer data among block diagram objects.

Waveform graph :- it ~~displays~~ displays one or more plots of evenly spaced measurements. The waveform graph plot of evenly spaced sample measurements.


Result :- Different waveforms were studied and generated.

Waveform Graph



Waveform Graph

Plot 0



Experiment No-4

Aim :- Strain & Temperature measurement with NI DAQ cards using LabView.

Software Used :- LabView

Theory :- Temperature Measurement

It is one of the most common types of physical measurements. Depending upon the desired accuracy, range and expense, we have several sensors options for measuring temp.

By using NI-USB-9213



Strain Measurement :-

Strain gauge are fundamental sensing devices that function as the building blocks of many other types of transducers, including pressure, load & torque extensively in structural test & monitoring applications.

Result :- We have successfully measured strain and temperature with NI DAQ cards using LabView


A) Temperature Measurement using Thermocouple

NI USB-9213



Pinout of NI – 9213

Thermocouple Connection Diagram





Front Panel


B) Strain Measurement using Strain Gauge

NI 9237


The following pin assignments appear on Channel 0-3.



NATIONAL INSTRUMENTS



Strain Connection Diagram



Previewing a Strain Measurement in MAX

Experiment NO- 5

Aim:- Signal Generation & frequency analysis by NI-DAQ cards.


Software Used:- LabView

Theory:- NI-9219, is designed for multipurpose testing with the NI-9219, you can measure signals from sensors such as strain gauge, resistance, temperature detectors, etc. Data acquisition is the process of measuring an electrical or physical phenomenon as such voltage etc. A s/m consists of sensors, DAQ measurements, hardware & a computer with programmable software.


<u>Input</u> :-	Parameter	Description
1)	Signals	— contains the i/p & o/p signals
2)	error in	— describes the error conditions that occur before this node runs

<u>Output</u> :-	Parameter	Description
1)	Amplitude	— amplitude of detected signal
2)	Frequency	— frequency of detected signal
3)	error out	— contains error information

Result:- Signal Generation & freq. Analysis were done successfully



Front Panel



Block Diagram

Experiment NO:- 6

Ans:- Labview - oscilloscope + Attribute Nodes, Menus
Software used:- Labview 2018

Theory:- Oscilloscope also known as CRO or DSO is a type of electronic test equipment that graphically displays varying signal voltages, usually as 2D plots of one or more signals as a functions of time.

Focus Control:- The control adjust CRT focus to obtain the shortest, most detailed trace.

Intensity Control:- It adjusts the brightness.

Beam Finder:- modern oscilloscope have direct coupled direction amplifier which means trace can be detected off screen.

Graticule:- A grid line that serves a reference marks for referring the displayed trace.


Time base Control:- Selects the horizontal speed of CRT's spot as it creates the trace.

Hold of control :- This sets the time after a trigger during which the sweep ~~so~~ circuit cannot be triggered again.


Vertical position control :- moves whole display up and down.

Horizontal position control :- moves whole display left and right.

Result :- Successfully generated function generator with oscilloscope in Labview.



Front Panel



Block Diagram

Experiment NO-7

Aim :- RC circuit and measuring time issues with DAD cards.

Software used :- LabView

Theory :- For resistance measurement DAD card can be used for acquisition of resistance in ohm. The dad card used is NI 9240. For a capacitor, capacitance is measured by NI 9283 given by


$$C = Q/V \quad \text{where } Q = \text{charge} \text{ \& } V = \text{voltage}$$

An RC circuit is an electrical circuit composed of resistors & capacitors. A first order RC circuit consists of 1 resistor & 1 capacitor.

The RC time constant, τ is equal to product of resistance & capacitance. It is time required to charge capacitor through resistor from initial voltage to 63.2% of applied DC voltage.

$$V_o = V(t) = V_o(1 - e^{-t/\tau})$$


Result :- RC circuit with its timing was studied in labview.



White Line: Step input with amplitude 5 – White Line

Red Line: RC Response

Front Panel



Block Diagram

Experiment NO - 8

Aim:- Opamp circuit & its characteristics

Software used:- LabView

Theory:- The formula Node is a convenient text based node, one can use to prepare mathematical operations on the block diagram formula nodes are useful for equations that have many variables

Inverting amplifiers:- It is one of amplifiers in which the output is exactly 180° out of phase with respect to input. output is an inverted amplified version of input; gain of inverting amplifier is given as:-
gain $\Rightarrow A_v = -\frac{R_f}{R_i}$

Non-Inverting Amplifier:- It is the one in which output is in phase with input.
gain $\Rightarrow A_v = 1 + \frac{R_f}{R_i}$

Voltage follower:- It is simply a circuit in which o/p follows input, means output voltage is same as that of input voltage


Differential Amplifier:-

$$\text{Gain} = \frac{-R_o}{R_L}$$

Result:- Successfully implemented different op Amp circuits in labview



Front Panel



Block Diagram

- V_{o1} = Voltage output of Inverting Amplifier
- V_{o2} = Voltage output of Non-Inverting Amplifier
- V_{o3} = Voltage output of Voltage Follower
- V_{o4} = Voltage output of Differential Amplifier
- V_{o5} = Voltage output of Instrumentation Amplifier
- V_{i1}, V_{i2} = Input Voltages
- R_o = Feedback Resistor
- R_g = Gain Resistance